

InfraSafe® Sediment Control Barrier

Assembly Instructions



- Insert two galvanized steel support pins in drainage holes as shown
- Align end tabs on orange barrier with corresponding cut-outs on black frame
- Snap barrier into frame
- Place assembled unit over access opening
- Contact Royal Environmental Systems, Inc. with any questions
651-462-2130