



# SpaceLock™ Pyramid Spacers



## Placement / Positioning Detail



### Inside (core) spacing:

- Place on horizontal wire at intersection
- Opening of clip facing down

### Outside (jacket) spacing:

- Place on vertical wire at intersection